

# 1D BarCode Scanner Quick Manual

V1.2



Version No.

## Introduction

This manual is a simple setup manual for 1D barcode scanner. Detailed User manual can be downloaded from the of Tcial website of obtained from lacial dealer.

## Program Settings

### Recal Default



Recall Default

Note: Scan "Recall Default" settings code, all settings of barcode scanner will be restored to factory default settings. The default settings is as the setting code with "\*" marked below.

### Interface Setting



\*USB Keyboard



USB COM

### Beper setting



\*Beeper on



beeper off

### Triggering mode Setting



\*Default scan mode



Automatic continuous scanning



Automatic flicker



Key delay

### Suffix Setting



ADD-ENTER



ADD-ENTER-TAB



ADD-ETX



Cancel the suffix

## Rs232 setting



Rs232 setting

### Data bit setting



7bits



8bits

### Parity bit setting



No Parity



Even Parity



Odd Parity

### Stop bit setting



\*1bits



2bits

## Baud rat setting



\*9600



600



1200



2400



4800



19200



38400



57600



115200

## Global Operations

### Language



\*American(default)



Canada (French)



Argentina (Latin)



German



Italy (Italian)



Belgium (Dutch)



Japan